

IJ-FMPRV

Insulation Jacket For FMPRV41, DSPRV41, FMPRV53

Description

Forbes Marshall Insulation Jackets are used for preventing heat energy loss from the body of the pressure reducing valve in service. The insulation jackets for the pressure reducing valve are available in ready to mount condition.

Available Versions

Available in version with velcro fitting suitable for	
FMPRV41	: DN 15 to 50
DSPRV41	: DN 40 and 50
FMPRV53	: DN 15 to 80

Limiting Conditions

Maximum metal surface temperature : 220°C

How to Order

Example: 1 No. Insulation jacket for DN 15 FMPRV41

Installation

Once the pressure reducing valve is installed, the insulation jacket can be fixed as follows.


- Place the jacket centrally from the bottom side of the pressure reducing valve.
- Slide the jacket up over the flanged/ threaded connection and pull the velcro flaps in to secure position.
- Wrap front and back of jacket around the valve and secure fully by using the side velcro flaps. Finally pull and tie the draw cords to minimise any gap that would allow air to flow or allow ingress of water.

Removal

Before removing the jacket, check if the pressure reducing valve is in service. If it is, then metal surface will be hot enough to burn, so suitable protective clothing (gloves, apron etc.) should be worn. Removal is the reverse of the installation procedure given above.

Handling

When the jacket is new the insulation material is fully enclosed within the inner and outer face and retained by stitching. In this condition no special protective clothing is required. However, if the inner and outer face becomes unstitched or damaged, so as to expose the insulation material then suitable protective clothing (e.g. gloves, safety glasses, face masks and overalls) should be worn when handling



Disposal

This product is not recyclable and is non-combustible. For disposal purpose consider the product to be mineral fibre and dispose off in accordance with local regulations.



Forbes Marshall
Krohne Marshall
Forbes Marshall Arca
Codel International
Forbes Solar
Forbes Vyncke
Forbes Marshall Steam Systems

Opp 106th Milestone
Bombay Poona Road
Kasarwadi, Pune - 411 034. INDIA
Tel : 91(0)20-27145595, 39858555
Fax : 91(0)20-27147413

Email : seg@forbesmarshall.com, ccmidc@forbesmarshall.com

© All rights reserved. Any reproduction or distribution in part or as a whole without written permission of Forbes Marshall Pvt Ltd, its associate companies or its subsidiaries ("FM Group") is prohibited.

Information, designs or specifications in this document are subject to change without notice. Responsibility for suitability, selection, installation, use, operation or maintenance of the product(s) rests solely with the purchaser and/or user. The contents of this document are presented for informational purposes only. FM Group disclaims liabilities or losses that may be incurred as a consequence of the use of this information.

B-85, Phase II, Chakan Indl Area
Sawardari, Chakan, Tal. Khed
Dist. Pune - 410 501. INDIA
Tel : 91(0)2135-393400

A-34/35, MIDC H Block
Pimpri, Pune - 411 018. INDIA.
Tel : 91(0)20-27442020, 39851199
Fax : 91(0)20-27442040

CIN No.: U28996PN1985PTC037806
www.forbesmarshall.com